



FAQ How to change the font size on the responder



A step by step guide




Changing responder font size



- Renaissance Responders can use either a small or large font size. To change the font size that you are using, follow the steps for updating the Responder firmware.
- When you choose the firmware version, choose the **odd-numbered version** if you want to use the **small font**
- choose the **even-numbered** version if you want to use the **large font**

- If the Responder is not already on, press the **On/Off** button.
- If necessary, enter the Personal Identification Number (PIN) for the student owner and press **Enter**.





- Press here to scroll down **Settings**

then, press **Select.**






- Press here to scroll down to **Firmware Update** then, press **Select**





- The Responder will ask if you want to stay connected to your Renaissance Receiver. Press **yes (True)**
- then, press **Select**.





- The Responder will search for the update and display it when it is found. Use the arrows to highlight the firmware version that you want to use. For each firmware release, you will see an even-numbered version and an odd-numbered version. Even numbers use the large font; odd numbers use the small font. Press **Select**.





- When the Responder asks you to, enter the administrator PIN (if you have not changed it, the PIN is 1234); then, press **ENTER**.

