

Neo User's Guide Addendum for UK

The items in this addendum are additions or corrections to the *Neo User's Guide* that apply specifically to the UK edition of Neo.

Note: Neos produced for the UK use an ISO keyboard layout; Neos produced for the US use an ANSI keyboard layout. This addendum refers to these layouts as “UK keyboards” and “US keyboards.”

Broken bar character

To produce the broken bar character (sometimes known as a vertical bar or pipe character) on a UK keyboard, press **ctrl-option-|**. (Neos that use a US keyboard cannot produce this character.)

Special characters

Some international characters require different keyboard commands on UK keyboards than those that are listed in the *Neo User's Guide* or what appears in Neo's help system. The table shown here lists the correct way to produce these characters on a UK keyboard.

Character	UK keyboard command
£ (pound sign)	shift-3
¢ (cent sign)	option-2
€ (euro sign)	option-4
™ (trademark)	option-shift-2

Alternate keyboard layouts

UK keyboards use a QWERTY keyboard layout. The layout cannot be changed. Therefore, the keyboard command to change keyboard layouts, as described in the *Neo User's Guide* and in Neo's help system, has no effect on UK keyboards. Additionally, the Control Panel setting to change keyboard layouts, as described in the *Neo User's Guide*, is not available on UK Neos.